

Data & Manual DTC Read/Clear Instructions Included in EASE Asian PC Scan Tool Version 8.x

Make	Year	ABS DTC	Airbag DTC	Engine DTC	Generic DTC	Generic Data	Trans DTC	Enh Engine	Enh Trans	Enh ABS	Enh Airbag
Honda	1994			X							
Honda	1995			X							
Honda	1996	X	X	X	X	X					
Honda	1997	X	X	X	X	X					
Honda	1998	X	X	X	X	X					
Honda	1999	X	X	X	X	X					
Honda	2000	X	X	X	X	X					
Honda	2001	X	X	X	X	X					
Honda	2002	X	X	X	X	X					
Honda	2003				X	X					
Honda	2004				X	X					
Honda	2005				X	X					
Honda	2006				X	X					
Honda	2007										
Honda	2008										
Make	Year	ABS DTC	Airbag DTC	Engine DTC	Generic DTC	Generic Data	Trans DTC	Enh Engine	Enh Trans	Enh ABS	Enh Airbag
Acura	1994			X							
Acura	1995			X							
Acura	1996	X	X	X	X	X					
Acura	1997	X	X	X	X	X					
Acura	1998	X	X	X	X	X					
Acura	1999	X	X	X	X	X					
Acura	2000	X	X	X	X	X					
Acura	2001	X	X	X	X	X					
Acura	2002	X	X	X	X	X					
Acura	2003				X	X					
Acura	2004				X	X					
Acura	2005				X	X					
Acura	2006				X	X					
Acura	2007										
Acura	2008										
Make	Year	ABS DTC	Airbag DTC	Engine DTC	Generic DTC	Generic Data	Trans DTC	Enh Engine	Enh Trans	Enh ABS	Enh Airbag
Isuzu	1994			X							
Isuzu	1995			X							
Isuzu	1996	X	X	X	X	X	X	X	X		
Isuzu	1997	X	X	X	X	X	X	X	X		
Isuzu	1998	X	X	X	X	X	X	X	X	X	
Isuzu	1999	X	X	X	X	X	X	X	X	X	
Isuzu	2000	X		X	X	X	X	X	X	X	
Isuzu	2001			X	X	X	X	X	X	X	
Isuzu	2002			X	X	X	X	X	X	X	
Isuzu	2003			X	X	X	X	X	X	X	
Isuzu	2004			X	X	X	X	X	X	X	
Isuzu	2005		X	X	X	X		X			X
Isuzu	2006		X	X	X	X		X			X
Isuzu	2007		X	X	X	X		X	X	X	X
Isuzu	2008			X	X	X		X	X		

Data & Manual DTC Read/Clear Instructions Included in EASE Asian PC Scan Tool Version 8.x

Make	Year	ABS DTC	Airbag DTC	Engine DTC	Generic DTC	Generic Data	Trans DTC	Enh Engine	Enh Trans	Enh ABS	Enh Airbag
Suzuki	1994			X							
Suzuki	1995			X							
Suzuki	1996			X	X	X					
Suzuki	1997			X	X	X					
Suzuki	1998			X	X	X					
Suzuki	1999			X	X	X					
Suzuki	2000			X	X	X					
Suzuki	2001			X	X	X					
Suzuki	2002			X	X	X					
Suzuki	2003			X	X	X					
Suzuki	2004				X	X					
Suzuki	2005				X	X					
Suzuki	2006				X	X					
Suzuki	2007				X	X					
Suzuki	2008				X	X					
Make	Year	ABS DTC	Airbag DTC	Engine DTC	Generic DTC	Generic Data	Trans DTC	Enh Engine	Enh Trans	Enh ABS	Enh Airbag
Kia	1994			X							
Kia	1995			X							
Kia	1996				X	X					
Kia	1997				X	X					
Kia	1998				X	X					
Kia	1999				X	X					
Kia	2000				X	X					
Kia	2001				X	X					
Kia	2002				X	X					
Kia	2003				X	X					
Kia	2004				X	X					
Kia	2005			X	X	X	X	X	X		
Kia	2006			X	X	X	X	X	X		
Kia	2007			X	X	X	X	X	X		
Kia	2008				X	X					
Make	Year	ABS DTC	Airbag DTC	Engine DTC	Generic DTC	Generic Data	Trans DTC	Enh Engine	Enh Trans	Enh ABS	Enh Airbag
Hyundai	1994			X							
Hyundai	1995			X							
Hyundai	1996				X	X					
Hyundai	1997				X	X					
Hyundai	1998				X	X					
Hyundai	1999				X	X					
Hyundai	2000				X	X					
Hyundai	2001				X	X					
Hyundai	2002				X	X					
Hyundai	2003				X	X					
Hyundai	2004				X	X					
Hyundai	2005			X	X	X	X	X	X		
Hyundai	2006			X	X	X	X	X	X		
Hyundai	2007			X	X	X	X	X	X		
Hyundai	2008				X	X					

Data & Manual DTC Read/Clear Instructions Included in EASE Asian PC Scan Tool Version 8.x

Make	Year	ABS DTC	Airbag DTC	Engine DTC	Generic DTC	Generic Data	Trans DTC	Enh Engine	Enh Trans	Enh ABS	Enh Airbag
Subaru	1994			X							
Subaru	1995			X							
Subaru	1996				X	X					
Subaru	1997				X	X					
Subaru	1998				X	X					
Subaru	1999				X	X					
Subaru	2000				X	X					
Subaru	2001				X	X					
Subaru	2002				X	X					
Subaru	2003				X	X					
Subaru	2004				X	X					
Subaru	2005				X	X					
Subaru	2006				X	X					
Subaru	2007				X	X					
Subaru	2008				X	X					